

**Vehicle Application: T.J. FRONT P/N 82202306**

*Please read instructions thoroughly before starting.*

**FRONT:**

**Tools Required:**

- Knife (Razor)
- 7/16" (11 mm) Socket/Driver
- 5/16" (8 mm) socket/driver
- Pliers
- Clean Cloth/Rag

**Package Contents:**

- 1 - LH Splash Guard
- 1 - RH Splash Guard
- 2 - Bolts (Wax Coated)
- 1 - Instruction Sheet

1. Clean and degrease front wheel well and flare where the Splashguard is to be located.
2. Refer to diagram and identify positions A and B, remove fender liner bolt and bottom flare bolt.
3. Identify position C bottom rear hole, remove plastic insert or bolt.
4. Position part, reinstall flare bolt and fender liner bolt. Then install supplied screw or removed bolt in position C. **Do not over tighten screws**.
5. Repeat procedure for other side.
6. Parts are made of (TPO) Thermo Plastic Olefin and are paintable. See reverse side of sheet for painting instructions.
7. Guards can be cleaned with any commercially available cleaner.

